

Frequently Asked Questions (FAQs) or APP NOTE

Delay Cables

Q: The coil of RG6 coax that comes with the system, how to utilize.

A: Depending on which system ordered, there are either one of two delay cables. Uncoil the loop and it will be very obviously which delay cable is short or long. Connect the correct delay cable to the designated LONG or SHORT delay connectors on the phase controller. These can remain coiled up. How they lay out in none critical.

- Hi-Z 2, 2-4 and Hi-Z 3 have one delay cable
- Hi-Z 4, 4-8PRO, Hi-Z 8A have 2 delay cables, LONG and SHORT

There is a short 2-3 foot RG6 cable and this connects the output of the phase controller to the input of the 75 ohm inline pre-amp. This has been confused for the short delay cable.